

NAIL DRILL DMJ-202 NTN PREMIUM

Model: **DMJ-202**

Certificate No.: **UNIB22101305HC-01**

DANE TECHNICZNE:

Rated Power: **65W**

No-load Power: **3-5W**

Input Voltage: **110V-240V 50Hz**

Output Voltage: **DC 12V 1A**

Rotational Speed: **35000 RPM**

NTN

PREMIUM

1. SAFETY INSTRUCTIONS:



1. Before first use, carefully read this instruction manual in full.
2. Before switching off the unit, set the speed control knob to the minimum position.
3. Do not use the device if the power cord, plug, housing, or any component is damaged, or if the device malfunctions.
4. Do not disassemble, repair, or modify the device yourself. Repairs must only be carried out by an authorized service center.
5. Do not use the device near heat sources, open flames, or in areas exposed to high temperatures.
6. This device is not intended for use by persons with reduced physical, sensory, or mental capabilities unless supervised by a person responsible for their safety.
7. Keep the device out of reach of children.
8. Connect the device only to a power supply that complies with the rated parameters specified on the product label.
9. Do not disconnect the handpiece cord while the device is in operation.
10. Do not leave the device unattended while switched on or connected to the power supply.
11. After use, or during extended periods of non-use, disconnect the device from the mains supply.
12. Do not pull the power cord, twist it, or expose it to mechanical damage.
13. Do not immerse the device, handpiece, or cables in water or any other liquids. Do not operate with wet hands.

2. PACKAGE CONTENTS:

- Main control unit
- Foot pedal
- Handpiece
- Handpiece holder
- 6 sanding bands
- 6 drill bits
- User manual
- Warranty card

3. DEVICE DESCRIPTION:

1. Working handpiece
2. Handpiece holder
3. Speed control knob
4. Power switch
5. Operation indicator light
6. Handpiece connection socket
7. Rotation direction switch
8. Power input socket
9. Foot pedal socket
10. Manual / Foot control mode selector switch



4. INSTALLATION AND CONNECTION:

1. Connect the handpiece cable to the appropriate socket on the unit.
2. Connect the foot pedal if it will be used.
3. Insert the appropriate drill bit into the handpiece.
4. Set the speed control knob to the minimum position.
5. Connect the device to the mains power supply.

6. OPERATING INSTRUCTIONS:

1. Switch on the device using the power button.
2. Set the selector switch to HAND mode (manual control).
3. Turn the speed control knob clockwise to increase speed.
4. Set the selector switch to FOOT mode to operate using the foot pedal.
5. To change the rotation direction, use the FWD / REV switch: **· FWD** = clockwise rotation, **· REV** = counterclockwise rotation

NOTE:

Beginners should start operation at the lowest speed setting.

Change the rotation direction only at minimum speed.

If the operation indicator does not light up, check the fuse.

7. CLEANING AND MAINTENANCE:

1. Before cleaning, switch off the device and disconnect it from the power supply.
2. Clean the device with a soft, dry cloth.
3. After use, remove the drill bit and store it safely.
4. Store the device in a dry, cool, and well-ventilated place.
5. Do not use acetone, solvents, or aggressive chemical agents for cleaning.
6. Do not pour water or other liquids onto the device.

IMPORTANT NOTICE:

- Returns or product replacement do not cover damage resulting from improper use by the customer.



In accordance with art. 13 sec. 1 of the Act of 11 September 2015 on used electrical and electronic equipment (Journal of Laws 2015 item 1688), we inform you about the correct handling of waste electrical and electronic equipment:

1. It is prohibited to place used electrical and electronic equipment together with other waste - this is confirmed by the marking in the form of a "crossed-out bin", which requires selective collection of this type of waste.
2. Electrical and electronic devices may contain hazardous substances, mixtures and components, which, after entering the environment, may pose a serious threat to the health and life of humans and living organisms.
3. Used electrical and electronic equipment should be transferred only to authorized collection points, the list of which should be included on the website of each Municipal Office.
4. Households play a key role in the waste management system for used electrical and electronic equipment due to the possibility of their direct transfer to authorized collection points and the elimination of undesirable social habits resulting in leaving waste equipment in places not intended for this purpose.

IMPORTER:

GNBLAB sp. z o.o.
ul. Piotrkowska 270
90-361 Łódź, Polska
hurt.gnb-lab.com
uwagi@gnb-lab.com

Produced for:

Allepaznokcie Michał Szewczyk
ul. Piotrkowska 270, Łódź
allepaznokcie.pl
Made in PRC