



SM-500 WAX HEATER

Model: **SM-500**

Certificate No.: **TST20230770420-2EC**

TST20230770420-1SC


TECHNICAL DATA:

Power: **100W**

Rated input: **220V-240V 50/60Hz**

Rated output: **1A**

Capacity: **500 ml**



IMPORTANT:

When using electrical appliances, especially in the presence of children, basic safety precautions must always be followed.

Please read this instruction manual carefully before using the appliance.

SAFETY INSTRUCTIONS:

1. Do not place or store the appliance where it may fall or be pulled into a bathtub, sink, or any other container filled with water.
2. Do not immerse the appliance in water or any other liquid. Keep the appliance and surrounding area dry at all times.
3. If the appliance falls into water, unplug it immediately. Do not reach into the water to retrieve the appliance.
4. As with all electrical appliances, electrical components may remain live even when the appliance is switched off. Always use caution during operation.

WARNINGS:

To reduce the risk of burns, electric shock, fire, or injury:

1. Do not use the appliance if:
 - the power cord or plug is damaged,
 - the appliance is not operating properly,
 - the appliance has been dropped or damaged,
 - the appliance has come into contact with water.
2. Close supervision is required when the appliance is used near children.
3. Keep the power cord away from heated surfaces.
4. Do not immerse the appliance in water or other liquids.
5. Do not allow the power cord to hang over the edge of a table or countertop where it may be pulled or accidentally snagged.
6. Always use the appliance on a stable and level surface.
7. Unplug the appliance after use and allow it to cool before cleaning or storing.
8. Do not wrap the power cord around the appliance during use.
9. The use of accessories not recommended by the manufacturer may result in hazards.
10. Always test the temperature of the wax or paraffin before placing hands into the appliance.
11. Use the appliance only for its intended purpose as described in this instruction manual.

OPERATING INSTRUCTIONS:

Please retain this manual for future reference.

WARNING:

Always test the temperature of the wax or paraffin before placing hands into the appliance.

1. Place the protective collar ring onto the rim of the appliance.
2. Remove the lid from the appliance.
3. Attach the holder to the wax container for safe handling.
4. Turn the temperature control knob to the "100" position and allow the wax to melt until a liquid consistency is achieved. The heating process takes approximately 15 minutes. For faster heating, it is recommended to keep the lid closed during operation.
5. Once the wax has completely melted, set the control knob to the middle position to maintain a constant working temperature. Before use, test the wax temperature by applying a small amount to the inside of the wrist. Adjust the temperature setting if necessary.
6. After use, remove the wax container using the holder while the appliance is still slightly warm.
7. Switch off the appliance by turning the control knob counterclockwise. Replace the lid to protect the wax from dust and contaminants.
8. Clean the appliance only when it is unplugged and still slightly warm.
9. For subsequent use, repeat steps 1-7.

CAUTION:

Extremely hot wax or paraffin may cause burns.

For professional use only.

For best results, please read the instruction manual carefully before operating the appliance.



In accordance with art. 13 sec. 1 of the Act of 11 September 2015 on used electrical and electronic equipment (Journal of Laws 2015 item 1688), we inform you about the correct handling of waste electrical and electronic equipment:

1. It is prohibited to place used electrical and electronic equipment together with other waste - this is confirmed by the marking in the form of a "crossed-out bin", which requires selective collection of this type of waste.
2. Electrical and electronic devices may contain hazardous substances, mixtures and components, which, after entering the environment, may pose a serious threat to the health and life of humans and living organisms.
3. Used electrical and electronic equipment should be transferred only to authorized collection points, the list of which should be included on the website of each Municipal Office.
4. Households play a key role in the waste management system for used electrical and electronic equipment due to the possibility of their direct transfer to authorized collection points and the elimination of undesirable social habits resulting in leaving waste equipment in places not intended for this purpose.

IMPORTER:
GNBLAB sp. z o.o.
ul. Piotrkowska 270
90-361 Łódź, Polska
hurt.gnb-lab.com
uwagi@gnb-lab.com
Made in PRC