

NAIL DUST COLLECTOR WITH CASSETTE FILTER 858-8

Model: 858-8

Certificate No.: HTT202411718E, HTT202411718L, HTT202412128R


TECHNICAL DATA:

Power: 80W

Nominal input: AC 100-240V 50Hz/60Hz

Nominal output: DC 12V 3A

Maximum speed: 4500 RPM



1. SAFETY OF USE:


1. Read this manual carefully before use to ensure proper operation. Keep it for future reference.
2. Replace the cassette filter regularly.
3. Do not touch the fan while the device is operating.
4. Clean the device only when dry.
5. Do not pull the power cord.
6. Ensure that the actual operating voltage corresponds to the device specifications.
7. Do not unplug the device while it is on and operating. Turn it off first.
8. Store and use the device in dry rooms only. Keep away from water and humidity. Otherwise, the device may stop working and/or be damaged.
9. After use, unplug the device from the power supply.
10. If the power cord is damaged, replace it with a new one of the same type in a service facility.
11. Do not make unauthorized modifications or changes to the device. Doing so will void the warranty.
12. Keep out of reach of children.

2. THE SET INCLUDES:

- Nail dust collector
- Power cable
- Cassette filter
- User manual
- Warranty card

3. DEVICE CHARACTERISTICS:

1. ON/OFF switch (I/O)
2. Fan
3. Power cable socket
4. Cassette filter



4. MAIN FUNCTIONS:

- An indispensable and essential tool for nail styling and podology.
- Strong suction power ensures the absorption of all dust and nail or skin fragments.
- Easy to use - simply place hands or feet near the fan opening and dust will be collected.
- A delicate and smooth surface ensures client comfort during treatments.

5. HOW TO USE:

1. Connect the device to the power supply.
2. Switch the device on using the power button. Once the fan starts, bring the hands or feet close to the nail dust collector opening.
3. After use, switch the device off and unplug it from the power source.



In accordance with art. 13 sec. 1 of the Act of 11 September 2015 on used electrical and electronic equipment (Journal of Laws 2015 item 1688), we inform you about the correct handling of waste electrical and electronic equipment:

1. It is prohibited to place used electrical and electronic equipment together with other waste - this is confirmed by the marking in the form of a "crossed-out bin", which requires selective collection of this type of waste.
2. Electrical and electronic devices may contain hazardous substances, mixtures and components, which, after entering the environment, may pose a serious threat to the health and life of humans and living organisms.
3. Used electrical and electronic equipment should be transferred only to authorized collection points, the list of which should be included on the website of each Municipal Office.
4. Households play a key role in the waste management system for used electrical and electronic equipment due to the possibility of their direct transfer to authorized collection points and the elimination of undesirable social habits resulting in leaving waste equipment in places not intended for this purpose.

IMPORTER

Made in PRC