

DUST COLLECTOR 858-6

- INSTRUCTION MANUAL



Technical specifications:

Maximum power: 80W
Power supply:
rated input: 100-240V
rated output: 12V 3A
RPM: 4500 rpm
Name: Nail dust collector
Model: 858-6

Features:

- Indispensable and indispensable tool for nail design and podiatry.
- Easy to use - just place your hands or feet near the fan opening and the dust will be absorbed.
- Ideal for both absorbing dust and fragments of nails or skin - from both hands and feet.

Instructions for use:

1. If the filter has not been installed, install it before connecting the device to the mains.
2. turn on the device with the switch. Once the fan starts working, you can bring your hands or feet close to the opening of the absorber.
3. When you have finished using the device, turn off the device and disconnect it from the power source.

Precautions and maintenance of the device.

- Do not touch the fan during operation.
- The device can only be cleaned dry.
- Do not bend or pull the power cord.
- Connect the device to a power supply that conforms to the device specifications.
- Do not disconnect the device from the mains while the device is on and running.
Be sure to turn it off beforehand.
- Store and use in dry areas. Keep away from water, moisture.
Otherwise the device may stop working and/or be damaged.
- Unplug the device from the mains after you have finished using it.
- If the power cord becomes damaged, replace it with a new one of the same type at a service facility.
- Making independent switches and changes to the device is prohibited.
- Opening the device is categorically forbidden and equivalent to loss of warranty, and the manufacturer assumes no responsibility for the correct and safe operation of the device
- Keep away from children.

IMPORTER

GNBLab
Michał Szewczyk, Piotr Malinowski s.c.
Piotrkowska 270
90-361 Łódź, Polska
gnb-lab.com

Made in P.R.C.