

# LOVEWAX WAX WARMER BWW1 - INSTRUCTION MANUAL



The warmer is ideal for all types of depilatory waxes.  
It melts any type of wax, including canned waxes, wax drops or black wax.

**MODEL: BWW1**

**Certificate no: B-E200730958, B-S200730959**

## Technical parameters:

- Power: 100W
- Power supply: 100W  
Input voltage: 220/230V  
output voltage: 220/230V
- Capacity 500ml
- Temperature range: 0°C-120°C
- Teflon coating



## Preparing the device for operation:

1. Connect the appliance to the power supply.
2. Remove the plastic lid from the warmer. Place canned wax or wax drops in the heater.
3. Switch on the warmer, set the temperature setting knob to MAX until the wax has melted. This process takes about 15 min, to speed it up, put the lid on the heater. The higher the temperature of the wax, the faster it will melt.
4. Once the wax has melted, reduce the temperature on the MED and, if necessary, adjust the temperature to a temperature that will not burn the skin. It is important to check the temperature of the wax before applying it, adjusting the temperature if necessary. The wax must not be too hot or too cold.
5. Proceed with the treatment.
6. When the treatment is complete, remove the wax can from the device, switch off the device and then cover it with the lid.
7. Clean the appliance after switching it off from the power supply, with a special agent, when it is slightly warm.

## Warnings:

- Ensure that the user does not have any skin diseases before performing the treatment.
- Do not directly touch the heating elements or the aluminium container.
- Do not heat the empty aluminium container.
- The appliance must be connected to a power supply conforming to the appliance specifications.
- Do not unplug the appliance from the mains whilst it is switched on and in operation.
- Stop using the appliance if you notice any unusual movement or noise.
- Store and use in dry areas. Keep away from water, moisture. Otherwise the device may stop working and/or become damaged.
- Unplug the appliance from the mains supply when you have finished using it.
- If the mains cable is damaged, replace it with a new one of the same type at a service centre.
- It is forbidden to make any unauthorised changes or modifications to the appliance.
- Opening the appliance is categorically forbidden and equivalent to forfeiting the guarantee, and the manufacturer assumes no responsibility for the correct and safe operation of the appliance.
- Keep away from children.

## IMPORTER

GNBLab

Michał Szewczyk, Piotr Malinowski s.c.

Piotrkowska 270  
90-361 Łódź, Polska  
gnb-lab.com

Made in P.R.C.